ECCJ-CEM®

Care & Maintenance

ECO-CEM® Care & Maintenance

The life and appearance of the ECO-CEM® panel installations can be prolonged by following the simple procedures listed below.

Dirt and Grit

The surface of ECO-CEM® is smooth thus dirt and dust do not stick. However, grit and sand can act like sandpaper on the finish causing scratches, dents and dulling.

Therefore, we recommend the placement of floor mats at entrances to trap debris and prevent scuffing, and to sweep or vacuum regularly.

Spills

Clean-up spills as they happen, rinse with water or, if needed, a normal household cleaning agent.

Damp Mop

Damp mopping is the fastest and most thorough way to deep-clean ECO-CEM® flooring. With medium to heavy traffic you may want to damp mop as often as once a week. Avoid oil soaps as they may stain the surface.

Use a mixture of neutral PH non-oily cleaner with water. Mop generously with this mixture, rinse the mop in clean water, wring the mop dry, and then mop once again for a final rinse.